


FIGURE 19



1. BUILD A FRAME OF 2" X 4" WOOD AROUND INLET. DRIVE STAKES INTO GROUND AT LEAST 12 INCHES.
2. DIG A 8 INCH DEEP TRENCH OUTSIDE FRAME.
3. ATTACH WIRE MESH TO FRAME EXTENDING MESH 2 INCHES INTO TRENCH.
4. ATTACH FILTER FABRIC TO FRAME EXTENDING FABRIC AT LEAST 8 INCHES INTO TRENCH. OVERLAP JOINT TO NEXT STAKE.
5. BACKFILL AND COMPACT SOIL IN TRENCH.

DROP INLET FILTER FABRIC BARRIER

FRANKLIN
ENGINEERING DEPT

FIGURE 19